

Fleece Vest

Size Chart						
	S	M	L	XL	2XL	3XL
Body Length	27.5	27.5	28.5	28.5	29.5	30
Body Width	21.5	23	25	27	29	30

BODY LENGTH

Lay garment flat (face down). Measure from center back neckline seam straight down to bottom of the front hem.

BODY WIDTH

Lay garment flat. 1" below the armhole flat measure the garment across the chest.